

## Network Configuration Guide

---

# **WSG-101 Building Automation System Gateway**

## **Copyright**

© 2011 Powercast Corporation. All rights reserved.

This document and the information in it are the property of Powercast and may not be used or reproduced in whole or in part, without the written permission of Powercast. Powercast reserves the right to revise this publication at any time and to make changes to its content without obligation to notify any person of such revision or change.

## **Trademarks**

Powercast<sup>®</sup>, the Powercast logo, Powercaster<sup>®</sup>, Powerharvester<sup>®</sup>, and Lifetime Power<sup>®</sup> are registered trademarks of Powercast Corporation in the United States and other countries.

# System Overview

The wired network interface for the WSG-101 is a ProtoCessor module from FieldServer Technologies, and is configured separately from other aspects of the WSG-101 gateway. The ProtoCessor module is referred to as a “FieldServer” in the instructions that follow.

Powercast will pre-configure the network interface as requested upon ordering. In the event network parameters need to be modified use the following instructions.

The gateway has three types of wired network interfaces: Ethernet, RS-485, and FTT-10. These physical interfaces support a range of network protocols depending on the particular interface. All changes to the wired network parameters are performed through an Ethernet interface. The Ethernet version has an Ethernet jack directly available through the side of the WSG-101 enclosure, and the Ethernet jack for the RS-485 and FTT-10 versions are available inside the enclosure by removing the enclosure lid.

**Note: Use a cross-over cable if connecting the FieldServer directly to a PC.**

Default network parameters:

IP address: [192.168.1.24]

For additional information please see:

## 1. Install Remote User Interface software

The first step to configuring parameters is to install the Remote User Interface software utility (RUInet). Download the utility software ZIP file and install.

Web page with link to install file

<http://www.protocessor.com/tech-support/utilities-and-design-documents.php>

Direct link to install file

<http://www.fieldserver.com/docs/downloads/Install.zip>

Remote User Interface (RUInet) User Manual

[http://www.fieldserver.com/docs/pdf/Utility\\_Manual\\_RuiNet.pdf](http://www.fieldserver.com/docs/pdf/Utility_Manual_RuiNet.pdf)

## 2. Selecting a FieldServer

After installing and starting RUInet, a screen similar to the one below is shown. If there are no firewall issues then a list of available and recently connected FieldServers is provided. If there is a potential network firewall issue as shown in Figure 1 it is best to directly enter the IP address of the device by selecting option <I> as shown in Figure 2.




Figure 1 – Start screen showing firewall issue and recently connected FieldServers




Figure 2 – Manually entering the IP address of the desired FieldServer

After connecting to the desired FieldServer, the following main menu is provided as shown in Figure 3.

### 3 – FieldServer Main Menu




Figure 3 – Main menu of FieldServer options

Most of the descriptions on the screen are self-explanatory, for additional details on any of these commands please download the following manual:

#### **Remote User Interface (RIUnet) Manual**

[http://www.fieldserver.com/docs/pdf/Utility\\_Manual\\_RuiNet.pdf](http://www.fieldserver.com/docs/pdf/Utility_Manual_RuiNet.pdf)

**Note - For versions of the WSG-101 that have the RS-485 or LON modules, the Ethernet configuration port is inside the enclosure. Remove the lid to attach the Ethernet cable.**

Screenshots for some of the options are provided below.

## Option B – FieldServer Information




Figure 4 – Option B, FieldServer Information

## Option O – Connection Overview





Figure 5 – Option O, Connection Overview

This screen shows the number of packets that are entering and exiting the FieldServer module.

## Option A – Data Array Overview



Data Array Name	Data Format	Length	Data Age
01- DA_TXID	UInt16	100	0.180s
02- DA_RSSI	Float	100	0.200s
03- DA_SECS	UInt32	100	0.200s
04- DA_S1	Float	100	0.220s
05- DA_S2	Float	100	0.240s
06- DA_S3	Float	100	1:18:20.230s
07- DA_S4	Float	100	1:18:20.280s
08- DA_S5	Float	100	1:18:20.320s
09- DA_S6	Float	100	1:18:20.360s
10- DA_S7	Float	100	1:18:20.420s
11- DA_S8	Float	100	1:18:20.490s

Keys: <R>reset      <Page Down> Next Page <Page Up> Previous Page      <ESC>  
<nn> Goto Data Array OR <G>oto Data Array

Figure 8 – Option A, Data Array Overview

The data arrays are defined as follows:

TXID = Transmitter ID (identifies the transmitter from which the sensor is receiving power)

PWR or RSSI = Indicator of sensor power source (9 = Batt OK, 0 = Batt LOW, 1-5 = RF Power Strength)

SECS = Time (seconds) since data was last updated

S1 - S8 = Sensor data (not all fields are used with each sensor)

Select the numbers (01-11) provided on the left side of the screen to see the individual data arrays.

## Option D – Download Configuration to FieldServer




Figure 9 – Option D, Downloading a Configuration file to a FieldServer.

Each FieldServer is configured by “downloading” a Comma-Separated Variable (CSV) text file. The file resides on the FieldServer and can be retrieved (uploaded), modified, and then downloaded back to the FieldServer. The file can be modified in a text editor like Windows Notepad or a spreadsheet like Microsoft Excel

A default configuration file is stored in the “Config” directory for the FieldServer Utilities software when the software is installed.

Example: C:\Program Files\FieldServer Utilities\Config

- L – selects the config file on the PC to be downloaded
- R – selects the config file on the FieldServer
- D – starts the download process (transfers file on PC to FieldServer)
- F – allows for updating the firmware (not recommended or supported by Powercast)
- O – enables uploading addition files (not recommended or supported by Powercast)

Default configuration files specific to the WSG-101 are located on the Powercast website:

<http://www.powercastco.com/resources/>



## Option U – Upload Configuration from FieldServer




Figure 10 – Option U, Uploading a configuration file from the FieldServer

Each FieldServer is configured by “downloading” a Comma-Separated Variable (CSV) text file. The file resides on the FieldServer and can be retrieved (uploaded), modified, and then downloaded back to the FieldServer. The file can be modified in a text editor like Windows Notepad or a spreadsheet like Microsoft Excel.

- R – selects the config file on the FieldServer to be uploaded
- L – selects the config file on the PC
- U – starts the upload process (transfers file in FieldServer to PC)
- O – enables uploading addition files (not recommended or supported by Powercast)

The only time the config file should be edited is to change the network Node\_ID (e.g. BACnet ID) of the device. It is recommended that all changes be made using Excel for readability. Be sure to save the file in CSV (Comma Separate Variable) format.




Figure 11 – screen shot showing uploading in progress

When the file transfer to the PC is completed it is possible to edit the file in SlickEdit, Excel, or Notepad as shown in the green message bar in Figure 12.




Figure 12 – screen shot showing uploading complete

## Option I – Change IP Address




Figure 13 – Option I, Change IP Address

Select this screen option to change the network parameters. Do not enable the device as a DHCP Server.

## 4 – Advanced Functions and Documentation

For advanced functions, configurations, and information not provided in this manual, please see the following site for additional instruction manuals.

<http://www.protocessor.com/tech-support/data-sheets-and-instruction-manuals.php>

## 5 – Technical Support

Powercast can assist with technical support for the FieldServer ProtoCessor network module. FieldServer technical support can also be contacted directly from Monday through Friday 8:00 A.M. to 5:00 P.M. Pacific Time.

Phone: 408-964-4444 or 888-509-1970 x141

Email: [support@protocessor.com](mailto:support@protocessor.com)