



## Operating Manual

## QuickServer FS-QS-3X10-F Start-up Guide



Revision: 1.H

Document No.:T18627

Print Spec: 10000005389 (F)



# fieldserver

*The Safety Company*

MSA Safety

1991 Tarob Court  
Milpitas, CA 95035

U.S. Support Information:

+1 408 964-4443  
+1 800 727-4377  
Email: [smc-support@msasafety.com](mailto:smc-support@msasafety.com)

EMEA Support Information:

+31 33 808 0590  
Email: [smc-support.emea@msasafety.com](mailto:smc-support.emea@msasafety.com)

For your local MSA contacts, please go to our website [www.MSA safety.com](http://www.MSA safety.com)

## Contents

<b>1</b>	<b>About the QuickServer</b>	<b>5</b>
1.1	Certification	5
1.2	Supplied Equipment	5
<b>2</b>	<b>Equipment Setup</b>	<b>6</b>
2.1	Mounting	6
2.2	Physical Dimensions	7
<b>3</b>	<b>Installation</b>	<b>8</b>
3.1	DIP Switch Settings	8
3.1.1	Bias Resistors	8
3.1.2	Termination Resistor	9
3.2	Connecting the R1 & R2 Ports	10
3.2.1	Wiring	10
3.2.2	Supported RS-485 Baud Rates by Protocol	10
3.3	10/100 Ethernet Connection Port	11
<b>4</b>	<b>Power up the Gateway</b>	<b>12</b>
<b>5</b>	<b>Connect the PC to the Gateway</b>	<b>13</b>
5.1	Connecting to the Gateway via Ethernet	13
5.1.1	Changing the Subnet of the Connected PC	13
<b>6</b>	<b>Setup Web Server Security</b>	<b>14</b>
6.1	Login to the FieldServer	14
6.2	Select the Security Mode	16
6.2.1	HTTPS with Own Trusted TLS Certificate	17
6.2.2	HTTPS with Default Untrusted Self-Signed TLS Certificate or HTTP with Built-in Payload Encryption	17
<b>7</b>	<b>Setup Network</b>	<b>18</b>
7.1	Using FS-GUI to Input Network Settings	19
7.2	Routing Settings	20
7.3	Ethernet 1 and Ethernet 2 Network Settings	21
7.4	WAN Mode Settings for ETH2	22
<b>8</b>	<b>Configuring the QuickServer</b>	<b>23</b>
8.1	Retrieve the Sample Configuration File	23
8.2	Change the Configuration File to Meet the Application	23
8.3	Load the Updated Configuration File	24
8.3.1	Using the FS-GUI to Load a Configuration File	24
8.3.2	Retrieve the Configuration File for Modification or Backup	25
8.4	Test and Commission the QuickServer	26
8.4.1	Accessing the FieldServer Manager	26
<b>9</b>	<b>Troubleshooting</b>	<b>27</b>
9.1	Lost or Incorrect IP Address	27
9.2	Viewing Diagnostic Information	28
9.3	Checking Wiring and Settings	29
9.4	Taking a FieldServer Diagnostic Capture	30

9.5	LED Functions .....	31
9.6	Factory Reset Instructions .....	32
9.7	Internet Browser Software Support .....	32
<b>10</b>	<b>Additional Information .....</b>	<b>33</b>
10.1	Change Web Server Security Settings After Initial Setup .....	33
10.1.1	Change Security Mode .....	34
10.1.2	Edit the Certificate Loaded onto the FieldServer .....	35
10.2	Change User Management Settings .....	36
10.2.1	Create Users .....	37
10.2.2	Edit Users .....	38
10.2.3	Delete Users .....	39
10.2.4	Change FieldServer Password .....	40
10.3	Specifications .....	41
10.4	Compliance with UL Regulations .....	42
<b>11</b>	<b>Limited 2 Year Warranty .....</b>	<b>43</b>

## 1 About the QuickServer

The QuickServer is a high performance, cost effective Building and Industrial Automation multi-protocol gateway providing protocol translation between serial/Ethernet devices and networks.

**NOTE: For troubleshooting assistance refer to Section 9 Troubleshooting, or any of the troubleshooting appendices in the related driver supplements. Check the MSA Safety website for technical support resources and documentation that may be of assistance.**

The QuickServer is cloud ready and connects with MSA Safety's Grid. See **Section 8.4.1 Accessing the FieldServer Manager** for further information.

### 1.1 Certification

#### BTL Mark – BACnet Testing Laboratory



The BTL Mark on the FieldServer is a symbol that indicates that a product has passed a series of rigorous tests conducted by an independent laboratory which verifies that the product correctly implements the BACnet features claimed in the listing. The mark is a symbol of a high-quality BACnet product.

Go to [www.BACnetInternational.net](http://www.BACnetInternational.net) for more information about the BACnet Testing Laboratory. Click [here](#) for the BACnet PIC Statement. *BACnet is a registered trademark of ASHRAE.*

### 1.2 Supplied Equipment

#### FieldServer Gateway

- Preloaded with two selected drivers. A sample configuration file is also loaded.
- All instruction manuals, driver manuals, support utilities are available on the USB drive provided in the optional accessory kit, or on the MSA website.

#### Accessory kit (optional) (Part # FS-8915-38-QS) includes:

- 7-ft Cat-5 cable with RJ45 connectors at both ends
- Power Supply -110/220V (p/n 69196)
- Screwdriver for connecting to terminals
- USB Flash drive loaded with:
  - Start-up Guide
  - FieldServer Configuration Manual
  - All FieldServer Driver Manuals
  - Support Utilities
  - Any additional folders related to special files configured for a specific FieldServer
  - Additional components as required - see driver manual supplement for details


## 2 Equipment Setup

### 2.1 Mounting

The gateway can be mounted using the DIN rail mounting bracket on the back of the unit.




## 2.2 Physical Dimensions



### 3 Installation

#### 3.1 DIP Switch Settings

##### 3.1.1 Bias Resistors



To enable Bias Resistors, move both the BIAS- and BIAS+ dip switches to the right in the orientation shown above.

The bias resistors are used to keep the RS-485 bus to a known state, when there is no transmission on the line (bus is idling), to help prevent false bits of data from being detected. The bias resistors typically pull one line high and the other low - far away from the decision point of the logic.


The bias resistor is 510 ohms which is in line with the BACnet spec. It should only be enabled at one point on the bus (for example, on the field port where there are very weak bias resistors of 100k). Since there are no jumpers, many QuickServers can be put on the network without running into the bias resistor limit which is < 500 ohms.

**NOTE:** See the [Termination and Bias Resistance Enote](#) for additional information.

**NOTE:** The R1 and R2 DIP Switches apply settings to the respective serial port.

**NOTE:** If the gateway is already powered on, DIP switch settings will not take effect unless the unit is power cycled.

### 3.1.2 Termination Resistor



If the gateway is the last device on the serial trunk, then the End-Of-Line Termination Switch needs to be enabled. **To enable the Termination Resistor, move the TERM dip switch to the right in the orientation shown in above.**

Termination resistor is also used to reduce noise. It pulls the two lines of an idle bus together. However, the resistor would override the effect of any bias resistors if connected.

**NOTE: The R1 and R2 DIP Switches apply settings to the respective serial port.**


**NOTE: If the gateway is already powered on, DIP switch settings will not take effect unless the unit is power cycled.**

### 3.2 Connecting the R1 & R2 Ports

**For the R1 Port only:** Switch between RS-485 and RS-232 by moving the number 4 DIP Switch left for RS-485 and right for RS-232 (see images in [Section 3.1 DIP Switch Settings](#)).

The R2 Port is RS-485.

Connect to the 3-pin connector(s) as shown below.



#### 3.2.1 Wiring

RS-485		RS-232	
BMS RS-485 Wiring	Gateway Pin Assignment	BMS RS-485 Wiring	Gateway Pin Assignment
RS-485 +	TX +	RS-232 -	TX +
RS-485 -	RX -	RS-232 +	RX -
GND	GND	GND	GND

**NOTE:** Use standard grounding principles for GND.

#### 3.2.2 Supported RS-485 Baud Rates by Protocol

The supported baud rates for either port is based on the protocol of the connected devices.


The following baud rates are supported for Modbus RTU:

2400, 4800, 9600, 19200, 38400, 57600, 76800, 115200

The following baud rates are supported for BACnet MS/TP:

9600, 19200, 38400, 76800, 115200

### 3.3 10/100 Ethernet Connection Port



The Ethernet Port is used both for Ethernet protocol communications and for configuring the gateway via the Web App. To connect the gateway, either connect the PC to the router's Ethernet port or connect the router and PC to an Ethernet switch. Use Cat-5 cables for the connection.

**NOTE: The Default IP Address of the gateway is 192.168.2.101, Subnet Mask is 255.255.255.0.**

**NOTE: The ETH2 port can be set to WAN mode to limit Ethernet traffic. See Section [7.4 WAN Mode Settings for ETH2](#) for details.**

**NOTE: ETH1 and ETH2 must be configured with IP Addresses on different IP subnets.**


## 4 Power up the Gateway

Check power requirements in the table below:

Power Requirement for QuickServer External Gateway		
	Current Draw Type	
QuickServer Family	12VDC	24VDC/AC
FS-QS-3X10-XXXX (Typical)	250mA	125mA
<b>NOTE: These values are 'nominal' and a safety margin should be added to the power supply of the host system. A safety margin of 25% is recommended.</b>		

Apply power to the QuickServer as shown below. Ensure that the power supply used complies with the specifications provided **Section in Section 10.3 Specifications0.1 Specifications**.


- The gateway accepts 9-30VDC or 24VAC on pins L+ and N-.
- Frame GND should be connected.



## 5 Connect the PC to the Gateway

### 5.1 Connecting to the Gateway via Ethernet

Connect a Cat-5 Ethernet cable (straight through or cross-over) between the local PC and QuickServer ETH1 (LAN Port).




#### 5.1.1 Changing the Subnet of the Connected PC

The default IP Address for the QuickServer is **192.168.2.101**, Subnet Mask is **255.255.255.0**. If the PC and QuickServer are on different IP networks, assign a static IP Address to the PC on the 192.168.2.xxx network.

For Windows 10:

- Use the search field in the local computer's taskbar (to the right of the windows icon ) and type in “Control Panel”.
- Click “Control Panel”, click “Network and Internet” and then click “Network and Sharing Center”.
- Click “Change adapter settings” on the left side of the window.
- Right-click on “Local Area Connection” and select “Properties” from the dropdown menu.
- Highlight  **Internet Protocol Version 4 (TCP/IPv4)** and then click the Properties button.
- Select and enter a static IP Address on the same subnet. For example:




- Click the Okay button to close the Internet Protocol window and the Close button to exit the Ethernet Properties window.

## 6 Setup Web Server Security


### 6.1 Login to the FieldServer

The first time the FieldServer GUI is opened in a browser, the IP Address for the gateway will appear as untrusted. This will cause the following pop-up windows to appear.


- When the Web Server Security Unconfigured window appears, read the text and choose whether to move forward with HTTPS or HTTP.



- When the warning that "Your connection is not private" appears, click the advanced button on the bottom left corner of the screen.




- Additional text will expand below the warning, click the underlined text to go to the IP Address. In the example below this text is “Proceed to 10.40.50.94 (unsafe)”.



- When the login screen appears, put in the Username (default is “admin”) and the Password (found on the label of the FieldServer).

**NOTE: There is also a QR code in the top right corner of the FieldServer label that shows the default unique password when scanned.**




**NOTE: A user has 5 attempts to login then there will be a 10-minute lockout. There is no timeout on the FieldServer to enter a password.**

**NOTE: To create individual user logins, go to Section 10.2 Change User Management Settings.**

## 6.2 Select the Security Mode

On the first login to the FieldServer, the following screen will appear that allows the user to select which mode the FieldServer should use.



**NOTE: Cookies are used for authentication.**

**NOTE: To change the web server security mode after initial setup, go to Section 10.1 Change Web Server Security Settings After Initial Setup.**

The sections that follow include instructions for assigning the different security modes.

### 6.2.1 HTTPS with Own Trusted TLS Certificate

This is the recommended selection and the most secure. **Please contact your IT department to find out if you can obtain a TLS certificate from your company before proceeding with the Own Trusted TLS Certificate option.**

- Once this option is selected, the Certificate, Private Key and Private Key Passphrase fields will appear under the mode selection.

**Certificate**

```
XzyMbQZFiRuJZJPe7CTHLcHOrHLowoUFoVTaBMYd4d6VGdNklKazByWKcNOL7mrX
A4IBAQBFM+IPvOx3T/47/EmaiXqE3bx3zEuBFJ6pWPlw7LHf2r2ZoHw+9xb+aNMU
dVwAehBMTMsnj2ERvQVp0xj3psSv2EJyKXS1bOYNRLsq7UzpwuAdT/Wy3o6vUM5
K+Cwf9qEoQ0LuxDZTIECt67MkcHMiuFi5pk7TRicHnQF/sfOAYOulduH0y9exlk9
EmHFVDIZt/cJUaF+e74EuSph+gEr0lQo2wmhvc7L22UXse1NoOfU2Zq0Eu1VV/tu
JRryaMWiRFEWuuzMGZtkFWVC+8q2JQsVcqiRWM7naobILeHOCMH+sKHJMCxDoXGt
vtZjpZUoAL51YXxWSVcyZdGiAP5e
-----END CERTIFICATE-----
```

**Private Key**

```
sHB0zZoHr4YQSDK2BbYVzzbl0LDuKtc8+JiO3ooGjoTuHngkeAj/fKfbTAsKeAzw
gKQe+H5UQNK0bdvZfOJrm6daDK2vVDmR5k+iUUhEj5N49uplroB97MQqYotzqfT+
THlbpg5t1SIK617k04ObKmHF5l8fck+ru545sVmpeezh0m5j5SURYZMvbq5daCu
J415NlihbEvxRF4UK41ZDMCvujioPcBKUWrb1a/3XXnDnM2K9xyz2wze998D6Wk46
+7aOFY9F+7j5ljmkoS3GYtwCyH5iP+mPP1K6RnuiD019wvGPb4dtN/RTnfd0eF
GYeVSkI9fxlxzDOFtdWRZbM/rPn4tmO1Xf8HqONVN1x/iaMynOXG4cukoi4+VO
u0rZaUEsI2zNkfrn7fAASm5NBWg202Cy9lAYnuujs3aALI5uGBeekA62oTMxlzx
-----END RSA PRIVATE KEY-----
```

**Private Key Passphrase**

Specify if encrypted

**Save**


- Copy and paste the Certificate and Private Key text into their respective fields. If the Private Key is encrypted type in the associated Passphrase.
- Click Save.
- A “Redirecting” message will appear. After a short time, the FieldServer GUI will open.

### 6.2.2 HTTPS with Default Untrusted Self-Signed TLS Certificate or HTTP with Built-in Payload Encryption

- Select one of these options and click the Save button.
- A “Redirecting” message will appear. After a short time, the FieldServer GUI will open.

## 7 Setup Network

Once the web server setup is complete, the FS-GUI landing page will appear.



The screenshot shows the MSA FS-GUI landing page. The top navigation bar includes the MSA logo, a search bar, and tabs for 'FieldServer Manager', 'Grid', and 'Grid Status'. The main content area has a 'Navigation' sidebar on the left with links for 'About', 'Setup', 'View', 'User Messages', and 'Diagnostics'. The main panel displays 'DCC000 QS.CSV v1.00a' with tabs for 'Status', 'Settings', and 'Info Stats'. The 'Status' tab is selected, showing a table of device parameters. The 'fieldserver' logo is in the bottom right corner.

Name	Value
Driver_Configuration	DCC000
DCC_Version	V6.05p (A)
Kernel_Version	V6.51c (D)
Release_Status	Normal
Build_Revision	6.1.3
Build_Date	2021-09-08 13:12:43 +0200
BIOS_Version	4.8.0
FieldServer_Model	FPC-N54
Serial_Number	1911100008VZL
Carrier Type	-
Data_Points_Used	220
Data_Points_Max	1500
Application Memory:	
Protocol_Engine_Memory_Used	0.66%
Memory_Used	947 kB

**NOTE:** The FieldServer Manager tab (see image above) allows users to connect to the Grid, MSA Safety's device cloud solution for IIoT. The FieldServer Manager enables secure remote connection to field devices through a FieldServer and its local applications for configuration, management, maintenance. For more information about the FieldServer Manager, refer to the [MSA Grid - FieldServer Manager Start-up Guide](#).

## 7.1 Using FS-GUI to Input Network Settings

To navigate from the FS-GUI page to the Network Settings page follow the below instructions:

- Find the Navigation tree across the left side of the screen.
- Click the arrow next to the FieldServer title/CN number to expand the tree.

The screenshot shows the FieldServer Manager (FS-GUI) interface. At the top left is the MSA logo. At the top right is the 'FieldServer Manager' title with a 'gr' icon. The main area has a navigation tree on the left and a detailed status table on the right.

**Navigation Tree:**

- DCC000 QS.CSV v1.00a
  - About
  - Setup
  - View
  - User Messages
  - Diagnostics

**Status Table:**

Name	Value
Driver_Configuration	DCC000
DCC_Version	V6.05p (A)
Kernel_Version	V6.51c (D)
Release_Status	Normal
Build_Revision	6.1.3
Build_Date	2021-09-08 13:12:43 +0200
BIOS_Version	4.8.0
FieldServer_Model	FPC-N54
Serial_Number	1929600190VZL
Carrier Type	-
Data_Points_Used	220
Data_Points_Max	1500

At the bottom are several buttons: Home, HELP (?), Contact Us, System Restart, System Reboot, System Time Synch, Reset Cycle Times, Logout, and a 'fieldserver' logo.

- Click on the arrow next to Setup to expand the tree.
- Click on Network Settings.

The screenshot shows the expanded navigation tree. The 'Setup' category is expanded, and the 'Network Settings' option is highlighted with a gray box.

**Navigation Tree:**

- DCC000 QS.CSV v1.00a
  - About
  - Setup
    - File Transfer
    - Network Settings
    - User Management
    - Security
    - Time Settings
  - View
    - User Messages
    - Diagnostics

## 7.2 Routing Settings

The Routing settings make it possible to set up the IP routing rules for the FieldServer's internet and network connections.

**NOTE: The default connection is ETH1.**

- as either ETH 1 or ETH 2
- Click the Add Rule button to add a new row and set a new Destination Network, Netmask and Gateway IP Address as needed.
- Set the Priority for each connection (1-255 with 1 as the highest priority and 255 as the lowest).
- Click the Save button to activate the new settings.

Set up the IP routing rules of your FieldServer for internet access and access to other networks.

If you want to reach another device that is not connected to the local network, you can add a rule to determine on which gateway the device must be routed to.

Interface	Destination Network	Netmask	Gateway IP Address	Priority
ETH 1	Default	-	10.40.50.1	255
ETH 1	10.40.50.10	255.255.255.255	10.40.50.1	100
ETH 1	10.40.50.15	255.255.255.255	10.40.50.1	50

**+ Add Rule**

**Cancel** **Save**

### 7.3 Ethernet 1 and Ethernet 2 Network Settings

- Enable DHCP to automatically assign IP Settings or modify the IP Settings manually as needed, via these fields: IP Address, Netmask, Gateway, and Domain Name Server1/2.

**NOTE: If connected to a router, set the Gateway to the same IP Address as the router.**


- Click Save to record and activate the new IP Address.
- Connect the FieldServer to the local network or router.

**NOTE: If the webpage was open in a browser, the browser will need to be pointed to the new IP Address of the FieldServer before the webpage will be accessible again.**

Network Status	
Connection Status	Connected
MAC Address	00:50:4e:60:45:1a
Ethernet Tx Msgs	27,652,114
Ethernet Rx Msgs	66,968,114
Ethernet Tx Msgs Dropped	0
Ethernet Rx Msgs Dropped	0

## 7.4 WAN Mode Settings for ETH2

- Click the blue WAN box to change the ETH 2 port to WAN mode.
  - This prevents all but allowed incoming traffic on the ETH 2 port it does allow a connection to the internet via port 80 & 443



- Scroll below the network settings to get to the firewall options with rules that allow specific incoming traffic (through setting rules) and outgoing options.

IP Address	Netmask (Optional)	Port Range	Description (Optional)
*	255.255.255.0	80,443,1024	Webpage and FieldServer Toc

### NOTE the following options for setting firewall rules:

- Add 1023 to the Port Range field to allow the FieldServer Toolbox access.
- Add 47808 to the Port Range field for BACnet access.
- Add 80 & 443 to the Port Range field for web browser access.
- Use a “\*” as a wild card for IP Address.


## 8 Configuring the QuickServer

### 8.1 Retrieve the Sample Configuration File

The configuration of the QuickServer is provided to the QuickServer's operating system via a comma-delimited file called "CONFIG.CSV".

If a custom configuration was ordered, the QuickServer will be programmed with the relevant device registers in the Config.csv file for the initial start-up. If not, the product is shipped with a sample config.csv that shows an example of the drivers ordered.

- In the main menu of the FS-GUI screen, go to "Setup", then "File Transfer", and finally "Retrieve".
- Click on "config.csv", and open or save the file.



The screenshot shows the FieldServer Manager (MSA) interface. The top navigation bar includes the MSA logo and the 'FieldServer Manager' title. The left sidebar, titled 'Navigation', contains a tree structure with 'DCC000 QS.CSV v1.00a' expanded, showing 'About', 'Setup' (which is expanded, showing 'File Transfer' selected), 'View', 'User Messages', and 'Diagnostics'. The main content area is titled 'File Transfer' and contains three sections: 'Update Configuration' (with a 'Choose Files' button and 'Submit' button), 'Retrieve' (listing 'config.csv'), and 'Delete' (with a 'Delete Configuration' button). At the bottom, there are buttons for 'Home', 'HELP (?)', 'Contact Us', 'System Restart', 'System Reboot', and 'Logout', along with a 'fieldserver' logo.


### 8.2 Change the Configuration File to Meet the Application

Refer to the FieldServer Configuration Manual in conjunction with the Driver supplements for information on configuring the QuickServer.

## 8.3 Load the Updated Configuration File

### 8.3.1 Using the FS-GUI to Load a Configuration File

- In the main menu of the FS-GUI screen, click “Setup”, then “File Transfer” and finally “Update”.
- Browse and select the .csv file, open, then click “Submit”.




- Once download is complete, a message bar will appear confirming that the configuration was updated successfully.
- Click the System Restart Button to put the new file into operation.

**NOTE: It is possible to do multiple downloads to the QuickServer before resetting it.**

### 8.3.2 Retrieve the Configuration File for Modification or Backup

To get a copy of the configuration file for modifying or backing up a configuration on a local computer, do the following:

- In the main menu of the FS-GUI screen, click “Setup”, then “File Transfer”.




The screenshot shows the 'File Transfer' section of the MSA FieldServer Manager. The left sidebar has a 'Navigation' menu with a tree structure. Under 'DCC000 QS.CSV v1.00a', 'Setup' is expanded, showing 'File Transfer' (which is selected and highlighted in blue), 'Network Settings', 'User Management', 'Security', and 'Time Settings'. Under 'View', there are 'User Messages' and 'Diagnostics'. At the bottom of the sidebar are 'Home', 'HELP (?)', and 'Contact Us' buttons. The main content area has a 'File Transfer' tab bar with 'Configuration' (selected), 'Firmware', and 'General' tabs. Below the tabs is a 'Update Configuration' section with a 'Choose Files' button (which says 'No file chosen') and a 'Submit' button. There is also a 'Retrieve' section with a link to 'config.csv' and a 'Delete' section with a 'Delete Configuration' button. At the bottom of the content area are 'System Restart', 'System Reboot', and 'Logout' buttons. The bottom right corner of the screen has a 'fieldserver' logo.

- Click the “config.csv” link under the “Retrieve” heading in the middle section of the screen.
  - The file will automatically download to the web browser’s default download location.
- Edit or store the file as desired.

**NOTE: Before using any backup configuration file to reset the configuration settings, check that the backup file is not an old version.**

## 8.4 Test and Commission the QuickServer

- Connect the QuickServer to the third party device(s), and test the application.
- From the landing page of the FS-GUI click on “View” in the navigation tree, then “Connections” to see the number of messages on each protocol.



The screenshot shows the MSA FieldServer Manager interface. The top navigation bar includes the MSA logo and the title 'FieldServer Manager'. The left sidebar, titled 'Navigation', contains a tree view with the following structure:

- DCC000 QS.CSV v1.00a
  - About
- Setup
- View
  - Connections
    - R1 - MODBUS\_RTU
    - ETH1 - Modbus/TCP
  - Data Arrays
  - Nodes
  - Map Descriptors
  - User Messages
  - Diagnostics

The main content area is titled 'Connections' and contains a table with the following data:

Index	Name	Tx Msg	Rx Msg	Tx Char	Rx Char	Errors
0	R1 - MODBUS_RTU	18,740	0	149,920	0	18,740
1	ETH1 - Modbus/TCP	0	0	0	0	0

At the bottom of the interface are several buttons: 'Home', 'HELP (?)', 'Contact Us', 'Reset Statistics' (highlighted in green), and 'Logout'.

**NOTE:** For troubleshooting assistance refer to Section 9 [Troubleshooting](#), or any of the troubleshooting appendices in the related driver supplements and configuration manual. MSA Safety also offers a technical support on the MSA Safety website, which contains a significant number of resources and documentation that may be of assistance.


### 8.4.1 Accessing the FieldServer Manager

**NOTE:** The FieldServer Manager tab (see image above) allows users to connect to the Grid, MSA Safety's device cloud solution for IIoT. The FieldServer Manager enables secure remote connection to field devices through a FieldServer and its local applications for configuration, management, maintenance. For more information about the FieldServer Manager, refer to the [MSA Grid - FieldServer Manager Start-up Guide](#).


## 9 Troubleshooting

### 9.1 Lost or Incorrect IP Address

- Ensure that FieldServer Toolbox is loaded onto the local PC. Otherwise, download the FieldServer-Toolbox.zip via the MSA Safety website.
- Extract the executable file and complete the installation.




- Connect a standard Cat-5 Ethernet cable between the user's PC and QuickServer.
- Double click on the FS Toolbox Utility and click Discover Now on the splash page.
- Check for the IP Address of the desired gateway.



## 9.2 Viewing Diagnostic Information

- Type the IP Address of the FieldServer into the web browser or use the FieldServer Toolbox to connect to the FieldServer.
- Click on Diagnostics and Debugging Button, then click on view, and then on connections.
- If there are any errors showing on the Connection page, refer to **Section 9.3 Checking Wiring and Settings** for the relevant wiring and settings.



The screenshot shows the FieldServer Manager interface. The top navigation bar includes the MSA logo, a search bar, and the text "FieldServer Manager". The left sidebar is titled "Navigation" and contains the following menu items:

- DCC000 QS.CSV v1.00a
  - About
- Setup
- View
  - Connections
    - R1 - MODBUS\_RTU
    - ETH1 - Modbus/TCP
  - Data Arrays
  - Nodes
  - Map Descriptors
  - User Messages
  - Diagnostics

The main content area is titled "Connections" and shows an "Overview" tab. Below it is a table titled "Connections" with the following data:

Index	Name	Tx Msg	Rx Msg	Tx Char	Rx Char	Errors
0	R1 - MODBUS_RTU	144	0	1,152	0	144
1	ETH1 - Modbus/TCP	0	0	0	0	0

At the bottom of the interface are several buttons: "Home", "HELP (?)", "Contact Us", "Reset Statistics" (which is highlighted in green), and "Logout". The "fieldserver" logo is in the bottom right corner.

### 9.3 Checking Wiring and Settings

No COMS on the Serial side. If the Tx/Rx LEDs are not flashing rapidly then there is a COM issue. To fix this problem, check the following:

- Visual observations of LEDs on the QuickServer. ([Section 9.5 LED Functions](#))
- Check baud rate, parity, data bits, stop bits.
- Check device address.
- Verify wiring.
- Verify the device is connected to the same subnet as the QuickServer.

Field COM problems:


- Visual observations of LEDs on the QuickServer. ([Section 9.5 LED Functions](#))
- Verify wiring.
- Verify IP Address setting.

**NOTE: If the problem still exists, a Diagnostic Capture needs to be taken and sent to support. ([Section 9.4 Taking a FieldServer Diagnostic Capture](#))**


## 9.4 Taking a FieldServer Diagnostic Capture

When there is a problem on-site that cannot easily be resolved, perform a Diagnostic Capture before contacting support. Once the Diagnostic Capture is complete, email it to technical support. The Diagnostic Capture will accelerate diagnosis of the problem.

- Access the FieldServer Diagnostics page via one of the following methods:
  - Open the FieldServer FS-GUI page and click on Diagnostics in the Navigation panel
  - Open the FieldServer Toolbox software and click the diagnose icon  of the desired device




- Go to Full Diagnostic and select the capture period.
- Click the Start button under the Full Diagnostic heading to start the capture.
  - When the capture period is finished, a Download button will appear next to the Start button



- Click Download for the capture to be downloaded to the local PC.
- Email the diagnostic zip file to technical support ([smc-support.emea@msasafety.com](mailto:smc-support.emea@msasafety.com)).

**NOTE: Diagnostic captures of BACnet MS/TP communication are output in a ".PCAP" file extension which is compatible with Wireshark.**

## 9.5 LED Functions



Tag	Description
<b>SS</b>	The SS LED will flash once a second to indicate that the bridge is in operation.
<b>ERR</b>	The SYS ERR LED will go on solid indicating there is a system error. If this occurs, immediately report the related "system error" shown in the error screen of the FS-GUI interface to support for evaluation.
<b>PWR</b>	This is the power light and should always be steady green when the unit is powered.
<b>RX</b>	The RX LED will flash when a message is received on the serial port on the 3-pin connector. If the serial port is not used, this LED is non-operational. RX1 applies to the R1 connection while RX2 applies to the R2 connection.
<b>TX</b>	The TX LED will flash when a message is sent on the serial port on the 3-pin connector. If the serial port is not used, this LED is non-operational. TX1 applies to the R1 connection while TX2 applies to the R2 connection.

## 9.6 Factory Reset Instructions

For instructions on how to reset a FieldServer back to its factory released state, see [ENOTE FieldServer Next Gen Recovery](#).

## 9.7 Internet Browser Software Support

The following web browsers are supported:

- Chrome Rev. 57 and higher
- Firefox Rev. 35 and higher
- Microsoft Edge Rev. 41 and higher
- Safari Rev. 3 and higher

**NOTE: Internet Explorer is no longer supported as recommended by Microsoft.**

**NOTE: Computer and network firewalls must be opened for Port 80 to allow FieldServer GUI to function.**

## 10 Additional Information

### 10.1 Change Web Server Security Settings After Initial Setup

**NOTE: Any changes will require a FieldServer reboot to take effect.**

- Navigate from the QuickServer landing page to the FS-GUI by clicking the blue “Diagnostics” text on the bottom of the screen.
- The QuickServer landing page is the FS-GUI.
- Click Setup in the Navigation panel.


The screenshot shows the FieldServer Manager (FS-GUI) interface. The top navigation bar includes the MSA logo, a search bar, and the text "FieldServer Manager". The main content area is titled "DCC000 QS.CSV v1.00a" and displays the "Status" tab. The status table contains the following data:

Name	Value
Driver_Configuration	DCC000
DCC_Version	V6.05p (A)
Kernel_Version	V6.51c (D)
Release_Status	Normal
Build_Revision	6.1.3
Build_Date	2021-09-08 13:12:43 +0200
BIOS_Version	4.8.0
FieldServer_Model	FPC-N54
Serial_Number	1911100008VZL
Carrier Type	-
Data_Points_Used	220
Data_Points_Max	1500

The navigation menu on the left shows a collapsed section for "DCC000 QS.CSV v1.00a" which includes "About", "Setup", "View", "User Messages", and "Diagnostics". The footer contains links for "Home", "HELP (?)", "Contact Us", "System Restart", "System Reboot", "System Time Sync", "Reset Cycle Times", "Logout", and the "fieldserver" logo.

### 10.1.1 Change Security Mode

- Click Security in the Navigation panel.




- Click the Mode desired.
  - If HTTPS with own trusted TLS certificate is selected, follow instructions in [Section 6.2.1 HTTPS with Own Trusted TLS Certificate](#)
- Click the Save button.

## 10.1.2 Edit the Certificate Loaded onto the FieldServer

**NOTE: A loaded certificate will only be available if the security mode was previously setup as HTTPS with own trusted TLS certificate.**

- Click Security in the Navigation panel.



- Click the Edit Certificate button to open the certificate and key fields.
- Edit the loaded certificate or key text as needed.
- Click Save.


## 10.2 Change User Management Settings

- From the FS-GUI page, click Setup in the Navigation panel.
- Click User Management in the navigation panel.

**NOTE:** If the passwords are lost, the unit can be reset to factory settings to reinstate the default unique password on the label. For recovery instructions, see the [FieldServer Next Gen Recovery document](#). If the default unique password is lost, then the unit must be mailed back to the factory.

**NOTE:** Any changes will require a FieldServer reboot to take effect.

- Check that the Users tab is selected.



User Types:

**Admin** – Can modify and view any settings on the FieldServer.

**Operator** – Can modify and view any data in the FieldServer array(s).

**Viewer** – Can only view settings/readings on the FieldServer.

### 10.2.1 Create Users

- Click the Create User button.

The screenshot shows the 'Create User' dialog box. At the top is the title 'Create User'. Below it is a 'Username:' field with the placeholder 'Enter a unique username'. Under 'Security Groups:', there are three checkboxes: 'Admin' (unchecked), 'Operator' (unchecked), and 'Viewer' (checked). To the right of the 'Password:' field is a red 'Weak' strength indicator. The 'Password:' field has the placeholder 'Enter password'. Below it is a 'Confirm Password:' field with the placeholder 'Confirm password'. A 'Generate Password' button is located below the password fields. At the bottom are 'Create' and 'Cancel' buttons.

- Enter the new User fields: Name, Security Group and Password.


- User details are hashed and salted**

**NOTE: The password must meet the minimum complexity requirements. An algorithm automatically checks the password entered and notes the level of strength on the top right of the Password text field.**

- Click the Create button.
- Once the Success message appears, click OK.

## 10.2.2 Edit Users

- Click the pencil icon next to the desired user to open the User Edit window.



- Once the User Edit window opens, change the User Security Group and Password as needed.

The 'Edit User' dialog box is shown. It has fields for 'Username' (User A), 'Security Groups' (Admin, Operator, and Viewer checkboxes, with 'Viewer' checked), 'Password' (Optional text field and 'Show passwords' checkbox), 'Confirm Password' (Optional text field), and a 'Generate Password' button. At the bottom are 'Confirm' and 'Cancel' buttons.

**Edit User**

**Username:**  
User A

**Security Groups:**

Admin  
 Operator  
 Viewer

**Password:**  
Optional

Show passwords

**Confirm Password:**  
Optional


Generate Password

**Confirm** **Cancel**


- Click Confirm.
- Once the Success message appears, click OK.

### 10.2.3 Delete Users

- Click the trash can icon next to the desired user to delete the entry.



- When the warning message appears, click Confirm.



#### 10.2.4 Change FieldServer Password

- Click the Password tab.

The screenshot shows the 'User Management' section of the FieldServer interface. On the left, a navigation menu lists 'DCC000 QS.CSV v1.00a' with 'About', 'Setup' (which is expanded to show 'File Transfer', 'Network Settings', 'User Management', 'Security', and 'Time Settings'), 'View' (which is expanded to show 'User Messages' and 'Diagnostics'). The 'User Management' tab is selected. In the main area, there are two text input fields: 'Password' and 'Confirm Password', both with placeholder text 'Enter password'. To the right of the 'Password' field is a red 'Weak' indicator. Below these fields are two buttons: 'Generate Password' and 'Confirm'.

- Change the general login password for the FieldServer as needed.

**NOTE:** The password must meet the minimum complexity requirements. An algorithm automatically checks the password entered and notes the level of strength on the top right of the Password text field.

### 10.3 Specifications



FS-QS-3X10-F	
<b>Electrical Connections</b>	One 3-pin Phoenix connector with: RS-485/RS-232 (Tx+ / Rx- / gnd) One 3-pin Phoenix connector with: RS-485 (+ / - / gnd) One 3-pin Phoenix connector with: Power port (+ / - / Frame-gnd) Two Ethernet 10/100 BaseT port
<b>Power Requirements</b>	<i>Input Voltage:</i> 9-30VDC or 24VAC <i>Current draw:</i> 24VAC 0.125A <i>Max Power:</i> 3 Watts      9-30VDC 0.25A @12VDC
<b>Approvals</b>	CE and FCC Part 15 C, UL 62368-1 and CAN/CSA C22.2, DNP 3.0 and Modbus conformance tested, WEEE compliant, RoHS3 compliant, REACH compliant, UKCA compliant
<b>Physical Dimensions</b>	4 x 1.1 x 2.7 in (10.16 x 2.8 x 6.8 cm)
<b>Weight</b>	0.4 lbs (0.2 Kg)
<b>Operating Temperature</b>	-20°C to 70°C (-4°F to 158°F)
<b>Humidity</b>	10-95% RH non-condensing

“This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his expense.

Modifications not expressly approved by FieldServer could void the user's authority to operate the equipment under FCC rules.”

**NOTE: Specifications subject to change without notice.**

#### 10.4 Compliance with UL Regulations

For UL compliance, the following instructions must be met when operating the QuickServer.

- The units shall be powered by listed LPS or Class 2 power supply suited to the expected operating temperature range.
- The interconnecting power connector and power cable shall:
  - Comply with local electrical code
  - Be suited to the expected operating temperature range
  - Meet the current and voltage rating for the FieldServer
- Furthermore, the interconnecting power cable shall:
  - Be of length not exceeding 3.05m (118.3")
  - Be constructed of materials rated VW-1, FT-1 or better
- If the unit is to be installed in an operating environment with a temperature above 65 °C, it should be installed in a Restricted Access Area requiring a key or a special tool to gain access.
- This device must not be connected to a LAN segment with outdoor wiring.

## 11 Limited 2 Year Warranty

MSA Safety warrants its products to be free from defects in workmanship or material under normal use and service for two years after date of shipment. MSA Safety will repair or replace any equipment found to be defective during the warranty period. Final determination of the nature and responsibility for defective or damaged equipment will be made by MSA Safety personnel.

All warranties hereunder are contingent upon proper use in the application for which the product was intended and do not cover products which have been modified or repaired without MSA Safety's approval or which have been subjected to accident, improper maintenance, installation or application; or on which original identification marks have been removed or altered. This Limited Warranty also will not apply to interconnecting cables or wires, consumables or to any damage resulting from battery leakage.

In all cases MSA Safety's responsibility and liability under this warranty shall be limited to the cost of the equipment. The purchaser must obtain shipping instructions for the prepaid return of any item under this warranty provision and compliance with such instruction shall be a condition of this warranty.

Except for the express warranty stated above, MSA Safety disclaims all warranties with regard to the products sold hereunder including all implied warranties of merchantability and fitness and the express warranties stated herein are in lieu of all obligations or liabilities on the part of MSA Safety for damages including, but not limited to, consequential damages arising out of or in connection with the use or performance of the product.