


5/64" Allen wrench used for branch test port and 0.048" 6 spline wrench used for thermostat

Products where TOOL-82 is used:

TK-1000 TK-6000 RK-500 R500 R503 **RK-504** R504 R516 **RK-532** R532 R537 RK-503 R539 R540 **RK-516** S515 T-82 **RK-539** RK-537 RK-540 SK-515








TOOL-85 AIR BULB




FITTING (WITH TUBE CONNECTORS)





AIR LINE WITH COMPRESSION FITTING







Used to test the air pressure. The needle end is inserted into test fitting AL-88 or AL-89. Products where AL-87 is used:

CP-8511

CP-8513

B-373

B-373 **FEMALE BRANCH TEE**

PP-8311



Used to interface gauge with branch line for branch pressure indication.

AIR LINE AL-87 NEEDLE ADAPTOR



PROPER INSTALLATION OF GAUGE ADAPTOR ASSEMBLY

GAUGE


N2-4

COMBINATION THERMOSTAT CALIBRATION/COVER SCREW WRENCH



HK-18 H18-301 H53-301 P341 PK-341 P541 T12 TK-12 TR12

PK-541 TKR-12 T13 TK-13 **TR13** TKR-13 T18 TK-18 **TR18 TKR-18** T19 **TR19** T23 T27 TK-23 TK-27 T24 T32 TK-32 T33 TK-33 T34 TK-34 T35 TK-35 T36 TK-36 TK-435 T436 T435 TK-436 T53-101 TKS-53-101



TOOL-110

3/32" HEXWRENCH Products where TOOL-110 is used: P323 PK-323 S510 SK-510 S511 SK-511 SK-520 S520 S530 SK-530 S540 SK-540

ROOM THERMOSTAT

MCS-GA

GAUGE ADAPTOR



Products where MCS-GA is used:

H18-301	HK-18	H53-301	HK-53
P341	PK-341	MCS-CV	MCS-CT
T12	TK-12	TR12	TKR-12
T13	TK-13	TR13	TKR-13
T18	TK-18	TR18	TKR-18
T19	TK-19	TR19	TKR-19
T23	TK-23	T24	TK-24
T27	TK-27	T32	TK-32
T33	TK-33	T34	TK-34
T35	TK-35	T36	TK-36
T435	TK-435	T436	TK-436
T460	TK-460	T53-101	TKS-53-101



Pneumatic Calibration Tool Kit

TOOL-95-1

STEPS

- 1. Measure temperature at thermostat.
- 2. Set dial to temperature measured.
- 3. Attach branch test gauges.
- 4. Adjust setpoint calibration screw to obtain desired branch pressure.
- 5. Adjust setpoint to desired control point.

invensys ...

Invensys Building Systems

1354 Clifford Avenue (Zip 61111) P.O. Box 2940 Loves Park, IL 61132-2940 United States of America

NOTICE

The thermal element of the room thermostat is very sensitive to temperature change. Do not affect its temperature by touching the bimetal or breathing on the thermostat. When calibrating the instrument, observe the wall box temperature frequently and reset the setpoint dial if required.

CAUTION

This information for reference only. Temperature controls are delicate instruments. Consult respective product General Instruction sheets before calibrating or adjusting the control.


F-17752-8 LITHO IN U.S.A. 1-93

TOOL-10



MAGNETIC SCREWDRIVER

Multiple purpose.




TOOL-11



CALIBRATION WRENCH FOR RK'S

Used for calibration of the proportional band, reverse and direct acting screws.




TOOL-74

Must be ordered separately. Not included in this tool kit.



INSERTION TOOL

Used for installing and removing 5/32" plastic air lines in small spaces.



TOOL-78 AL-362



TOOL-78 ADAPTOR



GAUGE

Used to adapt test gauge to branch test port for TK-1000, TK-6000 PN thermostats.



PROPER INSTALLATION OF GAUGE AND BRANCH TEE ASSEMBLY





ROOM THERMOSTAT

DUCT THERMOSTAT

TOOL-80-1



Manual changeover wrench used for TK-1201, TK-1301, TK-1601, TK-13000, TK-14000 series. Calibration wrench used for TK-1700 and TK-1700 arrive. 1800 series.

NOTE .

The hex nuts on the setpoint adjusting screws are a tension device only. They should not be loosened to make an adjustment.



15 PSIG BIMETAL CALIBRATION SCREW

