


Installation Manual

aSENSE Duct Conduit RL

CO₂ / temperature transmitter for mounting in ventilation ducts




- 1 Sampling probe
- 2 Sealing gasket
- 3 Largest locking nob
- 4 2 washers
- 5 2 screws

- 6 O-ring 29,2x3,53 (Factory supplied mounted in box)
- 7 PCB (Factory supplied mounted in box)
- 8 Snap-in lid
- 9 Set screw conduit connector
- 10 Temperature sensor



Mounting of aSENSE on to the duct.



- 11 Hole with 25 mm diameter
- 12 Temperature sensor with 135 mm cable mounted in the sampling probe

Mounting Instruction

Since there might be a substantial pressure difference in duct mounting applications, it is essential to avoid ambient air from suction into the duct mounting box. For correct function it is indispensable that the sealing of the box cover, the cable entry bushings, the cable feed through and the duct entrance are absolutely tight. The duct entrance may need extra sealing paste in order to prevent leakage. The PCB must be handed carefully and protected from electrostatic discharge.


- 1) **Mounting the tube:** Drill a hole (11) with 25 mm diameter (or 1 inch) for the sampling probe and two holes for the screws (5) into the air duct and mount the tube (1) with the gasket (2). The sampling probe should be mounted with the largest locking knob on top. The unit can be mounted with the air coming from the left or right.
- Attaching the sensor box is made to the sampling probe by a snap-in bayonet fitting. First, carefully stick the temperature probe (12) into the sampling probe.
 (1). Orient the box onto the sampling probe so that the box upside is on the same side as the largest locking knob (3). When the probe is fitted into the notches of the box, then turn the box clockwise until stop (see Figure 1). Position 1 indicates open where the box can be removed from the sampling probe. In position 2 the box is locked to the probe.

.



3) Electrical cable entry: The box has a factory mounted set screw conduit connector. Place the cable into the foam plug.

Insert the foam plug from below until it stops. Insert the EMT into the connector until it stops and tighten the screw.






If for some reason the PCB must be removed it must be handed carefully and protected from electrostatic discharge! Normally, removing the PCB is not required.



Electrical connections

The power supply has to be connected to + and - is considered as system ground. If the analogue output is connected to a controller *the same ground reference has to be used for the aSENSE RL unit and for the control system!* Unless different transformers are used, special precautions need to be taken.



<u>PLEASE NOTE!</u> The aSENSE signal and power supply grounds are common!

NOTE! The same ground reference has to be used for the aSENSE RL unit and for the control system!


Connect the power after mounting. The analogue output should be connected before measuring.

Connection Terminal	Function	Electrical Data	Remarks
~ +	Power (+)	24 VAC/DC+ (+-20%), 1W	
	Power ground (-)	24 VAC/DC-	See note 1!
Out(1)	Analogue Output 1 (+)	0-10 VDC or according to label	According to positions of Out(1) and start point jumpers. See note 2!
Out(2)	Analogue Output 2 (+)	Same as Output 1	According to positions of Out(2) and start point jumpers. See note 2!
5	Normally closed relay	Contact free relay	Triggered by register Out(3)
6	Relay COM	minimum load 1mA/5V rated load 0,5A/125VAC;	
7	Normally open	1A/24VDC	
8	Not used		

Note 1: The ground terminal is used as negative power supply DC input or AC phase ground (halfwave rectifier). A single transformer may be used for the entire system.

Note 2: aSENSE can deliver a voltage or a current loop for Out(1) / Out(2). To change between voltage and current output mode the hardware jumpers are used. There is one jumper for Out(1) and one for Out(2), so that one output can be a voltage output and the other a current output. Both, voltage output and current outputs, can have start points 0 % (0-10 VDC or 0-20mA) or 20% (2-10 VDC or 4-20mA). The same start point is used for both outputs. See the user manual.





Terminals and jumpers on aSENSE RL. The darker positions are default settings.

Dimensions

